Information
PrePaid-Electricity-Meter

(Modell UNI-BLZ 700)

To activate the display, press any button.

Recharging your PrePaid-Electricity-Meter

Press button **#** to enter the **key number**.
Enter the 10-digit key number and confirm by pressing button **#**.

Important: On your voucher for your key number is always a receipt number. The entry of the key numbers must always be made according to the order of the receipt numbers.
Example: Voucher no. 6 can only be entered if voucher no. 5 has already been entered.



Other functions of your PrePaid-Eletricity-Meter

1 Press button **1** to display the **current meter readings**.
T1 / 1.8.1 = Meter reading in daytime current
T2 / 1.8.2 = Meter reading in nighttime current (if available)

5 Press button **5** to display the **current remaining debt**:
You can see the remaining debt and the repayment, which is deducted daily from your credit balance

6 Press button **6** to display the **time slots**:
The meter does not switch off during these times. If you have used up your credit during these times, the meter waits until a time slot expires.

8 Press button **8** to display **the latest deposits.**
You can see the latest deposits made on the device.

0 Press button **0** to display the **extra credit**:
You can see how much extra credit can be added (usually 20 €). To activate the extra credit, press button **#**. The extra credit cannot be used a second time.

Albwerk GmbH & Co. KG, Eybstraße 98-102, 73312 Geislingen - Tel. (07331) 209 - 600, E-Mail: kundenservice@albwerk.de